

# ULTRA SLIMPAK® II MODEL WV468-2000

## True RMS AC Input Isolating Signal Conditioner

### Installation and Calibration Instructions

**NOTE:** The unit has been shipped with the Power Clips attached. Please remove the clips before installing the module on the DIN rail. If the Power Clips are chosen as the means to route power, they can be installed once the modules are in place on the DIN rail.

#### DIN Rail Mounting

The WV468 mounts on a 35mm TS35 DIN rail, by simply hooking one side of the mounting foot over the rail and pressing the module towards the rail until it locks into place. To remove the unit from the rail, place the tip of a flat-bladed screwdriver under the release clip on either the top or the bottom of the module and pry up until the module releases from the rail. See Figure 1.




Figure 1

the front side of the upper and lower terminal blocks for a positive fit. The board slides in where the switch and the switch position chart on the case can be viewed together.





Figure 2

#### Wiring Connections



Pin	Description
11	DC Power (+)
12	DC Power (-)
21	DC Power (+)
22	DC Power (-)
41	AC Input (hot)
42	AC Input (neutral)
51	Output (+)
52	Output Common

#### Input Range Configuration

Unless otherwise specified, the factory presets the Model WV468 as follows:

Input: mVAC  
Range: 0-500mV  
Output: DC Current  
Range: 4-20mA  
Reverse Out: Off  
Remote Cal: Off

1. For other ranges, refer to the SWITCH SETTINGS table. Reconfigure switches S1 and S2 for the desired input type and range.
2. Set position 1 of S1 to ON if a WVC16 will be utilized and remote calibration capability is desired.
3. Set position 2 and 3 of S1 for the desired output type.
4. Set position 4 of S1 to ON for reverse output operation.
5. Set positions 5-8 of S1 and 1 & 4 of S2 for the desired input range.

#### Power Connections

The power jumper clips (see Figure 2) are used to distribute power to a maximum of 16 modules. In applications using more than 16 modules, power wiring must be connected to the first and last module, and distributed to the remaining modules using the power clips. This technique allows for "hot swapping" of a module without interrupting power to the remaining units.

#### Opening the Case

The case can be opened by simultaneously pressing in on the two ribbed tabs located at the top and bottom of the front cap of the case and sliding out the circuit board. This provides easy access to the DIP switch for range selection. To close the case, slide the board back in until the two tabs lock firmly in place. This may require pressing on

## Switch Settings

Function	S1				S2	
	5	6	7	8	1	4
<b>Input Ranges</b>						
250V	■	■	■	■	■	■
150V	■	■	■	■	■	■
50V	■	■	■	■	■	■
20V	■	■	■	■	■	■
5V	■	■	■	■	■	■
500mV	■	■	■	■	■	■
150mV	■	■	■	■	■	■
50mV	■	■	■	■	■	■
100mA	■	■	■	■	■	■
20mA	■	■	■	■	■	■

Key: ■ = 1 = ON or Closed

Function	S1	
	2	3
<b>Output Ranges</b>		
0 to 10V	■	■
0 to 20mA	■	■
4 to 20mA	■	■

Key: ■ = 1 = ON or Closed

Function	S1	
	1	4
Remote Cal Enable	■	■
Reverse Out	■	■

Key: ■ = 1 = ON or Closed

input values. Once the maximum and minimum input values have been set, the Green and Red LEDs will be on. At that point simply press the CAL button rapidly 3 times and you will exit the calibration routine without effecting the last saved calibration for the operational output values.

1. Connect the input to a calibrated AC source and the output to a voltage or current meter. Apply power and allow the system to reach thermal equilibrium. Refer to Figure 3 for a detailed flow chart of the procedure. The section in the dotted-line box is all that is required for the user to calibrate operational input and output, and is all that is described in this procedure.

2. Adjust the input signal to the desired maximum and observe that the Green LED is on or flashing. Push the CAL button and hold for more than 4 seconds. The Yellow and Red LEDs should be on. Push the CAL button momentarily and the Yellow and Green LEDs will be on. From this point on, you can exit the calibration procedure at any step, without saving new data, by holding the CAL button for at least 4 seconds.

3. Apply the maximum input signal level desired and push the CAL button. The Yellow LED should now be on.

4. Apply the minimum input signal level desired and push the CAL button. The Green and Red LEDs should now be on. If you do not wish to change the output calibration, press the CAL button rapidly three times to exit the calibration routine.

5. Adjust the input signal upward until the output is at the desired maximum level (e.g. 20.00mA), and then push the CAL button. The Red LED should be on.

6. Adjust the input signal level downward until the output is at the desired minimum level (e.g. 4.00mA), and then push the CAL button. All three LEDs should now be on.

7. Push the CAL button once more to save the calibration data. The Green LED should be on if the input is within the calibrated range.

## Diagnostic LEDs

Other than when executing the pushbutton calibration routine, the LEDs blink under the following conditions:

**GREEN:** Flashes at 2Hz when the input is under range.  
Flashes at 8Hz when the input is over range.

**RED:** Flashes at 2Hz when the output is under range.  
Flashes at 8Hz when the output is over range.

An Under Range condition exists when the signal is lower than the operation low value minus 6.25% of operational span. An Over Range condition exists when the signal is higher than the operation high value plus 6.25% of operational span.

A voltage output short circuit can cause an under range condition (RED blinking at 2Hz rate). A current output open circuit can cause an over range condition (RED blinking at an 8Hz rate).

There could be two or more LEDs blinking at the same time, which means the module has more than one error condition. Only when all error conditions have been removed will the LEDs be back to normal (green on, red and yellow off).

## Calibration

For best results, calibration should be performed in the operating environment, mounted to a piece of DIN rail, allowing at least one hour for thermal equilibrium of the system. If pre-calibration on a test bench is desired, then an output load equal to the input impedance of the devices connected to the WV468 output is recommended, along with the warm-up period.

Note: Many applications do not require calibrating the output levels and simply utilize the default operational output ranges of the unit (0-10VDC, 0-20mA or 4-20mA). If the factory default calibration has been changed, the last saved operational output values are utilized. In those applications, the only calibration required is the operational




Figure 3: WV468 Calibration Flowchart

## Specifications

### Inputs

**RMS Voltage:** 50mV, 150mV, 500mV, 5V, 20V, 50V, 150V and 250V  
@ ±0.015% of FS accuracy  
**Impedance:** >100k ohms  
**Over-voltage:** 275Vrms  
**RMS Current:** 20mA and 100mA @ ±0.015% of FS accuracy  
**Impedance:** 10 ohms, typical  
**Over-current:** 200mA, protected by self-resetting fuse  
**Over-voltage:** 60V

### Frequency Range

40 to 400Hz

### Linearity

±0.1% of span, typical

### Pushbutton Adjustment

Effective zero offset: +95%  
Effective span turn-down: -95%

### Local Range Selection

By DIP switch

### Output

Voltage: 0 to 10V  
Source Impedance: <10 ohms  
Drive: 10mA

### Current

0 to 20mA  
Source Impedance: >100k ohms  
Compliance: 20V @ 20mA (1k ohms max)

### Output Accuracy

±0.05% of Full Scale

### Response Time

100mSec (10 to 90%)

### Stability

±100ppm of full scale/°C (±0.01%/°C)

### Output Ripple

0.2% of span, or 5mVrms, whichever is greater

### Output Impedance

Voltage Output: <10 ohms (source impedance)  
Current Output: >100k ohms

### Common Mode Rejection

120dB @ DC, >90dB @ 60Hz, or better

### Isolation

1800VDC or peak AC between input, output & power

### ESD Susceptibility

Capable of meeting IEC 801-2 level 3 (8kV)

### Power

9-30VDC  
2.0W Typ, 2.5W max

### Host Module Interface

IR link

### Size


DIN rail case – 0.5" wide (12.7mm), refer to Dimensions drawing

### Environmental

Operating Temperature: 0°C to +60°C (32 to 140°F)  
Storage Temperature: -25°C to +85°C (-13 to 185°F)  
Operating Relative Humidity: 15% to 95% RH non-condensing at 45°C  
Non-operating Relative Humidity: 90% RH non-condensing at 60°C for 24hrs


### Agency Approvals (EMC & Safety)

CE EN50081-1, EN50082-2, EN61010, pending.  
CSA C22.2, No. 0-M91, 142-M1987, pending and UL508, pending



## Dimensions

Dimensions are in mm (inches)



Eurotherm Controls  
741-F Miller Drive  
Leesburg, VA 20175-8993  
703-443-0000  
info@eurotherm.com

## Factory Assistance

For additional information on calibration, operation and installation contact our Technical Services Group:

**703-669-1318**  
actionsupport@eurotherm.com

HA136738WV468 Rev 1 - Copyright © Eurotherm, Inc 2006