

TECHNICAL INFORMATION SHEET – NUMBER 365

2400 SERIES PDSIO MODE 4 HOLDBACK DISABLE/ENABLE SWITCH]



12/17/98

ISSUED BY THE APPLICATIONS ENGINEERING DEPARTMENT

Please refer to TIS sheet #181 for the initial setup and wiring of the Master / Slave system. After that TIS sheet has been followed the remainder of this TIS will explain how to set up a switch on the Master controller that will either Enable or Disable the holdback feature for the entire system.

- First enter the Configuration level of the Master controller.
- Press the page button until the La or Lb is displayed
- Press the scroll button until i d is displayed (the lower display will show Log.i)
- Press the scroll button until Func is displayed
- Press the up or down arrows until Hbac is displayed in the lower display
- Exit the configuration level

Wiring of the switch for the contact closure that will Enable or Disable the holdback is shown below.

Logic input 1 signal +

Logic input 2 signal +

Logic input common

